

- **Open Kodi Kreations Wizard underneath Tools.**
- **Click on “(Kodi Kreations) Builds”. Click on “Emerald Goldserver Linux” > Fresh Install > Continue.**
- **Click on Force Close when it’s done. Let Kodi sit for a few minutes.**
- **Open File Manager underneath System.**
- **You will see lists on the left and right sides**
- **Go to the right and open “.update”**
- **Go to the left side and open .CoreELEC.**
- **IMPORTANT! Look at the top of your box to see which model it is and open the corresponding folder. For X92 models, look at the bottom to see if it says “2G” or “3G” and open X92-2G or X92-3G folder.**
- **You will now see 2 files “CoreELEC...” and another file that ends in “.dtb”. Press the menu button on the remote and choose “Select All”**
- **Press the menu button again and choose “Copy”**

Fix Advancedsettings file:

- **underneath Tools, open Kodi Kreations Wizard > Maintenance > System tweaks/fixes > quick configure advancedsettings. Click “Write File” at the bottom.**
- **Reboot the box so CoreELEC will now install and the correct advancedsettings file will take effect.**

Install new Kodi 18 appropriate build version:

Scroll down to Addons and click on it.

Go down to Program Addons and click to the right.

open Kodi Kreations Wizard.

Open “(Kodi Kreations) Builds”

“Emerald Live” is for live tv subscribers with TV Guide. Emerald Core is for non-subscribers without TV Guide. Choose the correct one for you.

Fresh Install

Continue

Force Close when it’s done

Let Kodi sit for a few minutes to allow addon updates and processes finish

Beast TV Kodi setup:

- **Open “Beast TV” underneath TV Guide**
- **enter your username and password.**
- **when asked if you want to integrate with the PVR Client, select No. If it asks you to select your device, click the back button on your remote.**
- **scroll down to “Extras” at the bottom.**
- **choose “Integrate With TV Guide” and select “PVR TV Guide”.**
- **click OK through all 5 “needs to restart” messages**
- **reboot the box**